

Compression Rod Bushings Installation Instructions SPL CRB Z33



Press out stock bushing using appropriate bushing press and driver.

For reference, the following Sears/Craftsman sockets will work as the driver and receiving cup:

Sears P/N 47784 1-11/16" socket Sears P/N 47793 2 3/8" socket

Check and clean the bore, file down any nicks in the bore as necessary.



Measure bushing bore of knuckle and measure diameter of new bushing with caliper. Confirm that new bushing is between 2/1000 - 4/1000 inch larger than the bore.

Using a hammer, lightly start the bushing into the bore, making sure bushing is square with the bore. Use press to continue pressing new bushing into compression rod.

<u>www.splparts.com</u> Questions?: 512-691-9002 tech@splparts.com



ONE-YEAR LIMITED WARRANTY AND DISCLAIMER

All SPL brand products are intended for **Off Road Use Only** and carry a one year limited warranty. See below for details. All other branded products carry their respective manufacturer warranty.

SPL PRO suspension products warranted to be free of defects in material and workmanship for one (1) year from the date of purchase.

If a product fails to meet specifications, SPL PARTS INC will, at its election, repair, replace, or make appropriate adjustment, if SPL PARTS INC determines to its satisfaction that the product is defective in material or workmanship, i.e. contains a defect arising out of the manufacture of the product and not a defect caused by other circumstances, including, but not limited to accident, misuse, abuse, unforeseeable use, neglect, alteration, improper installation, improper adjustment, improper repair, or failure caused by other equipment or interaction with other equipment. SPL PARTS INC is not responsible for labor charges, removal charges, installation, or other incidental or consequential costs. In no event shall the liability of SPL PARTS INC exceed the purchase price of the product. All parts for warranty claims must be returned to SPL PARTS INC in order for the claim to be processed.

SPL PARTS INC makes no other warranties, either expressed or implied, including limitation warranties as to merchantability or fitness for a particular purpose. SPL PARTS INC shall not be liable for, and buyer assumes all risk of, any advice or failure to provide advice by SPL PARTS INC to buyer regarding the product or use and installation of product. SPL PARTS INC shall not be liable for any special, incidental or consequential damages.

If the purchaser of the product shall fail to pay when due any portion of the purchase price, or fail to meet any terms required under contract agreed on at time of purchase, all warranties and remedies granted may be terminated.

Using any SPL arm as a tie/strap down point for a dyno session or transport will void the warranty.

www.splparts.com Questions?: 512-691-9002 tech@splparts.com